

# LITES Remote

Remote access to control panels MHU 116/117


## DPE-2 PERIPHERAL MODULE GSM (LTE)/LAN

### GSM (LTE) communicator

- 1 SIM card
- Sending of events to up to 8 set numbers
- Sending of all or selected events
- Setting via configuration program

### LAN connection

- 3 connectors for LAN connection
- Remote display and control of the system
- Connection of PC superstructure and other devices



## REMOTE DISPLAY



- Full display and control of the system
- Application for PC, smartphones and tablets
- Supports Android and iOS
- Remote connection via LAN or GSM (LTE)
- Connection via Peripheral module DPE-2
- Multilingual menu: CZ, SK, EN, HU
- Events downloading and sorting
- Status screen of saved profiles


App Store:



Google Play:



## GSM COMMUNICATOR



- Sending events to up to 8 phone numbers
- Set up SMS messages or calls
- Send all or selected events
- System status check SMS
- Option to turn off/on sending events
- Listing of selected events to up to 4 email addresses on set dates or for a specific period of time